



Working Together to Solve your Material Handling Needs

CPP 335 Plastic Pallet with Perimeter Base

CPP 336 Plastic Pallet with Cruciform Center and Perimeter Base

Step 1 Lay the CPP 330 plastic pallet face down on a hard flat surface. (Fig 1)



Fig 1



Fig 2

Step 2 Align the 335 or 336 bottom runner with the skid blocks by laying it on top of the blocks, snap side facing the blocks. (Figs 2-4)



Fig 3



Fig 4

Step 3 Secure a 2" x 4" x 4' piece of wood or other suitable object. If you have 2 people, the second person can apply the needed pressure with their foot.



Fig 5



Fig 6

Step 4 Firmly tap the center of the runner down until it snaps together with the center block. (Figs 5-6)



Fig 7



Fig 8

Step 5 Apply pressure with your foot on the bottom runner by leaning on the middle of the span between two blocks. (Figs 7-8)

Step 6 Starting with the center blocks, use the 2x4 or a foot and firmly press or tap on top of block until the bottom runner snaps into place. (Fig 9)



Fig 9

Step 7 Repeat step 5 until all of the joints are secure.

Note: Occasionally 1-2 of the tabs will snap off. This should not affect the carrying capacity of the pallet.

View Our Complete Line Of Plastic Pallets